

Description

AD-L8 is ultraconcentrated laundry destainer specifically formulated for use in commercial, healthcare and on premise laundries. The product can be used for all types of fabrics EXCEPT nylon and should be applied in the main wash at temp. between 75 - 90 C. AD-L8 is high temp. bleach system based on hydrogen peroxide.

NOTE : bloodstains will set when in contact with peroxide and as result will be hard to remove therefore its strongly advised to avoid any contact with peroxide bleach during the initial phase of wash. Its recommended to treat fabric with bloodstains with an enzymatic product in the pre-wash.

BENEFITS

- Excellent destainer for all types of fabric including coloured.
- Easy to dose.

Use Instructions

Dosing levels are dependent on wash classification
Dosage recommendation : 1 - 4 ml /Kg dry linen

Note That

AD-L8 is most effective at temp. > 75 C.
At these temp. the PH of the wash solution should be between 10 and 12.

PHYSICAL PROPERTIES

Appearance	Clear,colorless,liquid
Density, 20°C	1.132 g/ml
Active Oxygen	23.5 % by wt
H ₂ O ₂ conc.	35.5

